

Introduction to Ship Engine Room Systems

Alexander Arnfinn Olsen

ROUTLEDGE



Contents

<i>Preface</i>	xvii
<i>Acknowledgements</i>	xix
<i>Abbreviations, glossary, and terms used</i>	xxi
<i>Temperature conversion table</i>	xxv
<i>Introduction</i>	xxvii

PART I

Steering and propulsion systems

1 Rudder and steering gear	3
<i>How the rudder helps the ship to turn</i>	7
<i>The steering gear</i>	12
<i>Evaluating the steering gear</i>	17
<i>Steering gear system failure</i>	18
<i>Emergency steering system</i>	20
<i>Notes</i>	21
2 Propeller design and function	23
<i>Principles of propeller design and function</i>	24
<i>Classifications of propeller</i>	29
<i>Propeller dimensions</i>	30
<i>Propulsion system assembly</i>	31
<i>Propeller shaft</i>	31
<i>Marine gearbox</i>	33
<i>Stern tube and propeller shafts</i>	33
<i>Propeller boss</i>	34
<i>Boss control on CPP</i>	36
<i>Propeller maintenance and overhauling</i>	36
<i>Boring and sighting</i>	36
<i>Renewing the propeller</i>	38
<i>Side thrusters</i>	39
<i>Design and function of the thrusters</i>	40
<i>Side thruster maintenance</i>	42
<i>Notes</i>	42

3	Introduction to the main engine	45
	<i>Types of main engines</i>	46
	<i>Steam engines</i>	46
	<i>Reciprocating steam engine</i>	47
	<i>Steam turbine engines</i>	47
	<i>Nuclear powered</i>	47
	<i>Diesel engines</i>	48
	<i>Gas turbines</i>	49
	<i>LNG engines</i>	49
	<i>Other types of engines</i>	49
	<i>Electric only</i>	50
	<i>Diesel-electric</i>	50
	<i>Turbo-electric</i>	50
	<i>Stirling engine</i>	50
	<i>How main engines are installed inside the ship's engine room</i>	51
4	Key components of the main engine	55
	<i>Main bearings</i>	55
	<i>Types of main bearings</i>	56
	<i>Common bearing defects</i>	57
	<i>Engine brace and strut</i>	58
	<i>Common rail system</i>	59
	<i>Turbocharger</i>	61
	<i>Surge line</i>	61
	<i>Terms associated with turbocharger surge</i>	62
	<i>Categories of turbocharger surge</i>	62
	<i>Causes of turbocharger surge</i>	63
	<i>Preventing turbocharger surge</i>	63
	<i>Entablature</i>	64
	<i>Air bottle</i>	65
	<i>Jack bolts</i>	66
	<i>Piston, piston skirt, and piston rod</i>	67
	<i>Piston skirt</i>	67
	<i>Piston rods</i>	67
	<i>Trunk piston</i>	68
	<i>Tie rods</i>	68
	<i>Dampers and de-tuners</i>	69
	<i>Dampers</i>	69
	<i>De-tuners</i>	70
5	Main engine pre-start checks and monitoring	73
	<i>Engine monitoring</i>	74
	<i>Engine monitoring systems</i>	74
	<i>Understanding the indicator diagram</i>	75
	<i>Power balancing</i>	78

6 Slow steaming and economic fuel consumption	81
<i>Preparing to slow steam</i>	83
<i>Optimising the main engine for slow steaming</i>	85
<i>Optimisation of the ship's main engine</i>	85
<i>Defining economical fuel consumption</i>	86
<i>Performance curves</i>	86
<i>Economical fuel consumption</i>	88
7 Exhaust gas system and scrubbers	91
<i>Exhaust gas piping</i>	91
EGB	93
Silencer	93
Spark arrestor	93
Expansion joints	94
Exhaust gas scrubbers	94
Wet scrubbers	95
Open-loop scrubber system	99
Closed-loop scrubber system	100
Hybrid scrubber system	101
Dry scrubbers	101
Notes	102
8 Engine room lubrication systems	103
Lube oil systems	103
Main engine lubricating system	103
Turbocharger lubricating oil system	105
Cylinder lubrication system	105
Piston rod stuffing, the box, and scavenge space drainage system	106
Lube oil properties	106
Assessing the lube oil	107
9 Basic engine room machinery maintenance and troubleshooting	111
Principles of troubleshooting	111
Common faults and malfunctions	112
Crankshaft faults and malfunctions	115
Crankcase inspections	115
Main bearing faults and malfunctions	117
Bearing inspections and surveys	119
Fuel valve overhauling	120
Fuel changeover procedures	120
Overhauling the cylinder liner	122
Timing chain tightening and adjustments	124
Excessive water loss from the freshwater expansion tank	128
Overspeeding and prevention	129
Preventing overspeeding of engine	129

10 Mechanical measuring tools and gauges	131
<i>Workshop processes</i>	135
PART II	
Power generation	139
11 Marine diesel generators	141
<i>Summary of the marine electrical system on ships</i>	141
<i>Working principles of the marine generator</i>	144
<i>Marine power distribution</i>	144
<i>Marine emergency power</i>	144
<i>Estimating the power requirement for the ship</i>	145
<i>Starting and stopping the generator</i>	149
<i>Generator starting procedure – automatic start</i>	150
<i>Generator starting procedure – manual start</i>	150
<i>Generator stopping procedure – automatic stop</i>	151
<i>Generator stopping procedure – manual stop</i>	151
<i>Situations where the generator must be stopped immediately</i>	151
<i>Generator synchronisation</i>	153
<i>Emergency synchronising lamps (three-bulb method)</i>	154
<i>Maintenance and overhauling of the main generator</i>	155
<i>Decarbonisation (d'carbining)</i>	155
<i>Emergency generator</i>	158
<i>Emergency generator maintenance</i>	159
12 Marine electrical systems	161
<i>Main switchboard</i>	163
<i>Busbar</i>	164
<i>Governor</i>	166
<i>Classification of governors based on their operating principles</i>	168
<i>Maintenance of the governor</i>	170
<i>Droop</i>	170
<i>Speeder spring</i>	171
<i>Deadband</i>	171
<i>Hunting</i>	171
<i>Safety principles of the marine electrical system</i>	171
<i>Avoiding electrocution</i>	171
<i>Main switchboard safety devices</i>	172
<i>Air circuit breakers</i>	173
<i>Preferential trips</i>	174
<i>Blackout conditions</i>	174
13 Electrical distribution systems and redundancy	177
14 Air compressor	185
<i>Main components of the air compressor system</i>	190

<i>Safety features of the compressor</i>	191
<i>Air compressor maintenance</i>	191
<i>Air compressor starting and stopping procedures</i>	194
<i>Air compressor troubleshooting</i>	195
PART III	
Heating, ventilation, and air conditioning	197
15 Marine boiler	199
<i>Requirement 1 – compensating for heat loss</i>	199
<i>Requirement 2 – raising the fuel oil temperature</i>	200
<i>Requirement 3 – all other services</i>	201
<i>Boiler ratings</i>	201
<i>Procedures for starting and stopping the boiler</i>	203
<i>Boiler misfires and malfunctions</i>	204
<i>Marine boiler failures</i>	205
<i>Boiler feedwater contamination</i>	206
<i>Boiler blowdown procedures</i>	207
<i>Procedure for scumming and bottom blowdown</i>	209
<i>Advantages and disadvantages of boiler blowdown</i>	209
<i>Cleaning the gauge glass</i>	210
16 Central cooling system	211
<i>Heat exchangers</i>	213
<i>Shell and tube-type heat exchanger</i>	213
<i>Plate-type heat exchanger</i>	214
<i>Plate-fin heat exchanger</i>	215
<i>Dynamic scraped surface heat exchanger</i>	215
<i>Phase change heat exchanger</i>	216
<i>Spiral heat exchanger</i>	216
<i>Direct contact heat exchanger</i>	216
<i>Charge air cooler</i>	216
<i>Inter- and aftercoolers (for air compressors)</i>	216
17 Refrigeration and air conditioning	219
PART IV	
Water management systems	227
18 Ballast water management	229
<i>Ballast water exchange methods</i>	230
<i>BWM plan and implementation</i>	232
<i>Record keeping</i>	234
<i>Ballast tanks on ships</i>	236
<i>Ballast tank monitoring</i>	238
<i>Ballast tank protection</i>	238

<i>Ballast tank inspections</i>	239
<i>Performing ballasting operations</i>	239
<i>Ballast water treatment</i>	241
<i>Ozone generator for ballast water treatment</i>	244
<i>Ballast water system maintenance</i>	245
<i>MARPOL annex I</i>	247
<i>Control of the discharge of oil under MARPOL annex I, regulation 4</i>	248
<i>Discharges in special areas</i>	248
<i>Discharges from oil tankers</i>	248
<i>Discharges from oil tankers in special areas</i>	249
<i>Complying with MARPOL annex I</i>	249
<i>Certificates, plans, and records under MARPOL annex I</i>	249
<i>Other essential requirements of MARPOL annex I</i>	251
<i>Roles and responsibilities under MARPOL annex I</i>	252
<i>Complying with the ballast water convention</i>	253
<i>Notes</i>	255
19 Oily water separator	257
<i>Design, construction, and working principles of the OWS</i>	258
<i>Operating the OWS</i>	259
<i>OWS maintenance</i>	261
<i>Oil discharge and monitoring and control system on oil tankers</i>	264
<i>Sludge production and management</i>	265
<i>Sludge tanks</i>	266
<i>Oily water evaporation and sludge incineration</i>	266
<i>Engine room bilge water generation</i>	267
<i>Cargo-hold bilge water generation</i>	268
<i>Good bilge management practices help improve OWS performance</i>	268
<i>Construction and working principles of the waste incinerator</i>	270
<i>Good practices for the incinerator</i>	272
<i>Ship oil pollution emergency plan (SOPEP)</i>	273
<i>Notes</i>	274
20 Wastewater management	275
<i>Design and construction of the sewage treatment plant</i>	275
<i>Special area regulations</i>	277
<i>Maintenance and checks</i>	278
<i>Reducing marine pollution from ships</i>	279
<i>Notes</i>	280
21 Freshwater generation	281
<i>Operating the freshwater generator</i>	282
<i>Reverse osmosis</i>	282
22 Pipes, tubes, bends, and valves	285
<i>Bends and elbows</i>	286

Short-radius and long-radius elbows	286
Mitre bends	288
Pipe fittings	288
Valves	293
Gate valve	293
Globe valve	295
PART V	
Engine room tanks and bunkering operations	301
23 Main fuel, diesel, and lube oil tanks on ships	303
Fuel and diesel oil tanks	304
Lubricating oil tanks	304
Tank inspections	305
Tank cleaning	308
Preparations to be done before cleaning the ship's tanks	309
During the tank cleaning	309
After the tank cleaning	309
Tank maintenance	309
24 Bunkering operations	311
Oil bunkering procedures	312
LNG bunkering procedures	314
Bunkerage disputes	317
Coriolis flow metre	317
Fuel oil bunkering malpractices	319
Tricks of the trade	320
Fuel oil storage on ships	327
Fuel oil consumption calculations	328
Measuring and reporting fuel oil consumption	328
Position, arrival, and departure reports	330
Determining the fuel bunkered and fuel in tanks	330
Measuring and reporting distance travelled	331
Method to measure hours underway	332
Emission factors	332
Information to be submitted to the IMO ship fuel oil consumption database	332
Notes	333
PART VI	
Engine room fires and emergency response	335
25 General emergency drills, alarms, and emergency systems	337
General alarms and emergencies	337
Engineer's call and alarms	338
Engine room drills and training procedures	338

26 Engine room explosions and fires	341
FCP	341
Crankcase explosions	342
Starter air-line explosion	343
Purifier room fires	343
Scavenge fires	344
Exhaust gas boiler fires	345
Incinerator fires	347
Electrical insulation fires	347
Battery room fires	348
Bacteria fires	348
27 Engine room drills, firefighting procedures and apparatus	351
Fire drills	351
Preventative measures and firefighting appliances	352
Sprinkler system: automatic fire detection, alarm, and extinguishing system	354
CO ₂ firefighting systems	355
ISC	356
Firefighting on oil tankers	358
Notes	360
28 Engine room flooding	361
Leaks from machinery and equipment	361
Leaks from the overboard valve	361
Flooding caused by cracks and fissures in the ship's hull or sideboard	362
Watertight bulkheads and flooding prevention	362
Watertight doors	366
SOLAS rules relating to watertight bulkheads	367
PART VII	
Engine room watch procedures	369
29 Engine room watch procedures	371
Engine room watchkeeping	373
30 Engine room logbook entries and checklists	375
Engine room logbooks and records	375
Manned engine room checklists	377
Engine department departure checklist	377
24 hours prior to departure	377
Six hours prior to departure	377
One hour prior to departure	378
15 minutes prior to departure	378
Checks to be made when the main engine is running	378

<i>Checks to be made when the vessel is full away</i>	379
<i>Engine department arrival checklist</i>	379
<i>One hour before the estimated time of arrival</i>	379
<i>On arrival at port</i>	380
<i>UMS checklists</i>	380
<i>Notes</i>	384
<i>Appendix: Recommended reading for marine engineers</i>	385
<i>Index</i>	389